



Pos.	Qt.	Componenti	Components	Composants	Componentes	Materials
1	1	Supporto di aspirazione	Suction support	Support d'aspiration	Soporte de aspiración	AISI 304/Wr 14301
2	1	Giunto di traino	Drive coupling	Manchon d'entraînement	Casquillo	AISI 304/Wr 14301
3	1	Rondella di spallamento	Counter thrust bearing washer	Plateau de contre-butée	Arandela de empuje	AISI 304/Wr 14301
5	1	Camicia albero	Sleeve	Chemise	Camisa	AISI 304/Wr 14301
6	1	Supporto lato aspirazione	Suction support	Support d'aspiration	Soporte de succión	NORYL GFN3    Rubber
7	1	Disco	Disc	Disque	Disque	NORYL GFN3
8	1	Bussola distanziatrice	Spacer sleeve	Douille entretoise	Casquillo espaciador	NORYL GFN2
9	1	Camicia albero	Sleeve	Chemise	Camisa	AISI 304/Wr 14301
10	1	Camera premente	Discharge casing	Discharge casing	Cuerpo tórico	NORYL GFN2    Rubber
11	N	Disco	Disc	Disque	Disque	NORYL GFN3
12	N	Diffusore	Diffuser	Diffuseur	Difusor	NORYL GFN2
13	N	Girante	Impeller	Roue	Impulsor	NORYL GFN2
14	1	Tubo distanziale	Interstage diffuser casing	Entretoise	Distanciador	AISI 304/Wr 14301
15	1	Bussola distanziatrice	Spacer sleeve	Douille entretoise	Casquillo espaciador	NORYL GFN2
16	1	Camicia albero	Shaft bush	Bearing sleeve	Casquillo eje	AISI 304/Wr 14301
17	1	Camera premente	Discharge casing	Corps de refoulement	Cuerpo tórico	NORYL GFN2    Rubber
18	1	Otturatore valvola	Wing valve	Soupape du clapet de retenue	Clapeta	AISI 304/Wr 14301
19	1	Mandata	Discharge Head	Refoulement	Cuerpo de impulsion	AISI 304/Wr 14301

N = Numero di componenti variabili dal tipo di pompa.  
 N = Number of components variable according to the type of pump.  
 N = Nombre composants variables selon le type de pompe.  
 N = Número de componentes variable según el tipo de bomba.